UNIVERSAL BEARING CUP INSTALLER



This installer adjusts to fit bearing cups from 3.63" - 6.50" O.D. It replaces over two dozen plates and drivers. Simply adjust the jaws to fit the cup I.D., lock the jaws, slip the new cup on and drive it home with a hammer.

Order No	o. Description	
7180 Universal bearing cup installer. Wt., 10 lbs.		

ASSEMBLE YOUR OWN "CUSTOM-MADE" DRIVER TOOLS

Order No.



These sets include discs and handles for custom seal driver assembly to provide a pilot (to prevent cocking), a spacer (so force is applied on the proper area) and a driver (for even force dist.). Discs range from 0.50" thru 4.50" diameters in 0.06" increments. Each set includes a handy plastic box with pre-cut tool tray.



27793	STARTER SET. Contains handle and discs especially selected to provide the driver sizes most frequently needed. Maximum utility at a modest investment! Wt., 4.00 lbs.	
Order No.	Description	
27794	BASIC SET. Wide coverage, low investment! Includes 41 discs and two handles. Size range: 0.50" - 3.00" diameter. Wt., 22.00 lbs.	
27795	BIG JOB SET. Used for servicing large components. You get coverage of 3.06" thru 4.50" diameter with the 24 discs and handle provided. Wt., 45.00 lbs.	
27797	MASTER SET. For maximum coverage. Three handle sizes and all 65 discs listed in chart below are included. Range: 0.5" thru 4.50" diameter. Wt., 68.00 lbs.	
212377	TOOL ORGANIZER BOARD. Will accommodate all components of 27797 Master Set. Tools not included. Wt., 5.00 lbs.	

Description


	DISCS					
	Order No.	Discs	Order No.	Discs	Order No.	Discs
		(in.)		(in.)		(in.)
	27491	0.50	27512	1.81	27534	3.19
	27492	0.56	27513 †	1.88	27535	3.25
	27493 †	0.63	27514	1.94	27536	3.31
	27494	0.69	27515	2.00	27537	3.38
	27495 †	0.75	27516	2.06	27538	3.44
	27496	0.81	27517	2.13	27539	3.50
	27497 †	0.88	27518	2.19	27540	3.56
	27498	0.94	27519	2.25	27541	3.63
	27499 †	1.00	27520	2.31	27542	3.69
N	27500	1.06	27521	2.38	27543	3.75
ı	27501 †	1.13	27522	2.44	27544	3.81
ı	27502	1.19	27523	2.50	27545	3.88
ı	27503 †	1.25	27524	2.56	27546	3.94
ı	27504	1.31	27525	2.63	27547	4.00
ı	27505 †	1.38	27526	2.69	27548	4.06
ı	27506	1.44	27527	2.75	27549	4.13
	27507 †	1.50	27528	2.81	27550	4.19
	27508	1.56	27529	2.88	27551	4.25
	27509 †	1.63	27530	2.94	27552	4.31
	27510	1.69	27531	3.00	27553	4.38
	27511 †	1.75	27532	3.06	27554	4.44
			27533	3.13	27555	4.50

	† Items	contained	in	27793	starter	set
--	---------	-----------	----	-------	---------	-----

SET COMPONENTS		
Order No.	Description	
10012 †	1/4"-20 UNC X 0.88" *	
10020 †	1/4"-20 UNC X 1.25" *	
10854 †	1/4"-20 UNC X 1.75"	
10855 †	1/4"-20 UNC X 2.75" *	
12001 †	1/4"-20 UNC X 2.25" *	
27487 †	Small Handle 5" X 3/4" Dia.	
27488	Med. Handle 6" X 1-1/4" Dia.	
27489	Large Handle 6" X 1-5/8" Dia.	
27490	Extension Tube	
7350 †	Allen Wrench	



* Socket head cap screw.



These sets have the proper-size driver for any seal, bearing or bushing installing job. Select the proper-size discs, attach to handle with cap screws and strike with hammer.

263 powerteam.com