



Platinum™ Plus Gold Lightweight Body Filler

01131 • 01130 • 01132 • 31135 • 31139

Technical Data Sheet

August 2015

3M Part No.(s)	3M Part Descriptor(s)
01131	3M™ Platinum™ Plus Gold Lightweight Body Filler - One gallon can - 102 fl oz, 3.0 L, 0.80 US gal
01130	3M™ Platinum™ Plus Gold Lightweight Body Filler - Three gallon mechanical dispenser pail - 2.2 gallons, 8.3L, 282 fl oz.
01132	3M™ Platinum™ Plus Gold Lightweight Body Filler - Three gallon air dispenser cartridge - 2.2 gallons, 8.3L, 282 fl oz.
31135 31139	3M™ Platinum™ Plus Gold Lightweight Body Filler - Five gallon air dispenser pail - 3.75 gallons, 14.2L 3M™ Platinum™ Plus Gold Lightweight Body Filler - Five gallon air dispenser pail - 3.75 gallons, 14.2L hardener included

Product Description 3M™ Platinum™ Plus Gold Lightweight Body Filler is a premium gold colored body filler, that offers excellent surface adhesion to properly prepared steel, galvanized steel, aluminum, E-coat, sheet molded compound (SMC) and fiberglass reinforced polyester (FRP), concrete and wood substrates. 3M™ Platinum™ Plus Gold Lightweight Body Filler is formulated with Stain-free/Tack free resin and is compatible with most base coat/clear coat and waterborne paint systems.

- Features**
- Creamy formula provides easy mixing & spreading
 - Adhesion Promoted formulation
 - Tack Free / Stain Free resin
 - Vacuum Processed to minimize pinholes

Typical Physical Properties **Note: The following technical information and data should be considered representative or typical only and should not be used for specification purposes.**

	Part A - Filler	Part B - Cream Hardener
Container	PN 01131 - One gallon metal can PN 01130 - Three gallon mechanical dispenser metal pail PN 01132 - Three gallon air dispenser fiber cartridge PN 01135 - Five gallon air dispenser metal pail PN 31139 - Five gallon air dispenser metal pail kit	1-2.75 oz. plastic tube 2- 3.5 oz plastic tubes 2- 3.5 oz plastic tubes No hardener 3-3.5 oz plastic tubes
Base	Polyester resin with styrene monomer	Benzoyl Peroxide
Density	8.05 lb/gal	10.0 lb/gal
Color	Gold	Blue
Flash Point	88°F / 31°C	N/A
Viscosity @ 77°F (25°C) - Brookfield Viscometer	120,000 - 204,000 cps	70,000 - 150,000 cps

3M™ Platinum™ Plus Gold Lightweight Body Filler

01131 • 01130 • 01132 • 01135 • 31139

Product Uses Two component polyester compound used to fill dents, dings, gouges and other cosmetic imperfections on bare steel, galvanized steel, aluminum, sheet molded compound (SMC) and fiberglass reinforced polyester (FRP). May also be used on many industrial and architectural surfaces needing minor repairs.

Typical Performance Properties **The following times have been determined with ambient air temperature and substrate temperature @ 77°F (25°C) and are considered typical values.**

SHAPE SAND TIME:

8 to 12 minutes when mixed with 2% hardener by weight @ 77°F (25°C)

FINISH SAND TIME:

20 minutes when mixed with 2% hardener by weight @ 77°F (25°C)

RECOMMENDED APPLICATION TEMPERATURE:

Above 45°F (7°C)

SERVICE TEMPERATURE:

Min. -20°F (-29°C) Max. 180°F (82°C)

MINIMUM HARDENER:

1.5%

MAXIMUM HARDENER:

2.75%

Note: The following technical information and data should be considered representative or typical only and should not be used for specification purposes.

Lap Shear, Steel to Steel:	1,180 psi	ASTM D1002
Lap Shear, Galvanized to Galvanized:	920	ASTM D1002
Lap Shear, Aluminum to Aluminum:	550 psi	ASTM D1002
Tensile Strength:	1,350 psi	ASTM D638
Shore D hardness @ 24 hrs:	67	ASTM D2240
Flexural Strength:	1,790 psi	ASTM D790 Procedure A
Shrinkage:	0.81%	LTM 855.0084

3M™ Platinum™ Plus Gold Lightweight Body Filler

01131 • 01130 • 01132 • 01135 • 31139

Directions for Use

PN 01130, when attaching the plastic dispensing valve, **DO NOT OVER TIGHTEN** this will cause damage to the threads and will not stay attached to the pail.

1. Clean the repair area using soap and water followed by a wax & grease remover/surface cleaner. Sand the surface as needed with grade P40 to P80 3M™ abrasive.

Note If grinding, most substrates use 60 grit Cubitron™ II grinding disc, for aluminum use 80 grit Cubitron™ II disc followed by 3M™ P80 on an orbital sander. When repairing galvanized steel, e-coat, primed/ painted surfaces or aluminum, sand with grade P80 3M™ abrasive to remove the paint/primer. Blow off with clean dry compressed air and re-clean the surface using a clean paper or cloth towel and a wax & grease remover/surface cleaner.

2. Apply the required amount of body filler to a clean mixing surface. (Do not use discarded cardboard as a mixing surface as contamination may occur.) The correct hardener to filler ratio = 3 inch diameter circle approximately 1/2 inch thick of filler to a 3 inch strip of cream hardener.
3. Mix the body filler and cream hardener thoroughly, to a uniform color. Gel time/setting time is approximately 3-5 minutes @ 75°F (24°C) using 2% hardener as prescribed. Spread the filler on the mixing board, being sure to break any air bubbles that were introduced during mixing.
4. Apply a thin layer using firm pressure to ensure maximum adhesion being sure to “wet out” the surface completely. Apply additional filler in layers, building up the damaged area higher than the surrounding surface. Maximum filler thickness should not exceed 1/4 inch. Allow curing time of 20 minutes.
5. Sand the filler to the proper contour with 3M™ abrasives, using the following recommended grade sequence: P40, P80, P180. **Note:** If more filler is needed blow off with clean dry compressed air and follow steps 2 through 6.
6. Wait approximately 45 minutes before applying primer and paint, always follow your paint company’s recommended procedures.

Applications

Repair of cosmetic surface imperfections in properly prepared auto body, industrial, and architectural substrates.

Storage and Handling

HANDLING

Do not eat, drink or smoke when using this product. Wash exposed areas thoroughly with soap and water. Keep out of the reach of children. Keep container closed when not in use. Avoid breathing of dust created by cutting, sanding, grinding or machining. For industrial or professional use only. Avoid eye contact with dust or airborne particles.

STORAGE

When stored at the recommended conditions in original, unopened containers, this product has a shelf life of 16 months from the date of manufacture. Store in a dry area at 65-80°F (18-27°C) for optimal shelf life.

3M™ Platinum® Plus Gold Lightweight Body Filler

01131 • 01130 • 01132 • 01135 • 31139

Precautionary Information

Refer to Product Label and Material Safety Data Sheet for Health and Safety Information before using this product. Read all directions and warnings on container for safe and proper application.

Safety Considerations

Material Safety Data Sheets (MSDS) are available from 3M™ at www.3M.com/MSDS or upon request through your nearest Sales office. MSDS sheets are provided to help customers satisfy their own handling, safety and disposal needs, and those required by local applicable health and safety regulations. MSDS sheets are updated regularly. Therefore, please request and review the most current MSDS before handling or using any product.

Customer Notice

3M encourages its customers to review their applications of 3M products from the standpoint of human health and environmental quality. To help ensure that 3M products are not used in ways for which they were not intended or tested, 3M personnel are willing to assist in dealing with ecological and product safety considerations. If assistance is needed, please contact your 3M representative

Technical Information

The technical information, recommendations and other statements contained in this document are based upon tests or experience that 3M believes are reliable, but the accuracy or completeness of such information is not guaranteed.

Product Use

Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.

Warranty, Limited Remedy, and Disclaimer

Unless an additional warranty is specifically stated on the applicable 3M product packaging or product literature, 3M warrants that each 3M product meets the applicable 3M product specification at the time 3M ships the product. 3M MAKES NO OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY OR CONDITION ARISING OUT OF A COURSE OF DEALING, CUSTOM OR USAGE OF TRADE. If the 3M product does not conform to this warranty, then the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.

Limitation of Liability

Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted, including warranty, contract, negligence or strict liability.

For Additional Health and Safety Information



Automotive Aftermarket Division

3M Center, Building 223-6N-01
St. Paul, MN 55144-1000
1-877-666-2277 (1-877-MMM-CARS)
www.3MCollision.com

3M and Platinum are trademarks of 3M Company.
Printed in U.S.A.

©3M 2011 P.N. 01121, 01171, 01231, 01271, 31311 (4/11)